

D-Power™ Digivice
Version 3中英文說明書
Chinese & English InstructionNOT INTENDED FOR SALES OR DISTRIBUTION
IN THE USA, CANADA OR EUROPEManufactured by
BANDAI(H.K)CO., LTD.
Room 2902, 29/F, United Centre,
95 Queenway, Hong Kong.

內容 CONTENTS

1. 什麼是 D-POWER DIGIVICE ? WHAT IS A D-POWER DIGIVICE?

2. 設定 SETUP

●如何更換電池
How to change battery3. 音量及還原
SOUND & RESET

●聲音 Sound

●還原操作 Reset operation

4. 選擇你的DIGIMON伙伴
SELECTING YOUR PARTNER DIGIMON5. DIGI-指令
DIGI-COMMANDS

●狀況 Status

●地圖 Map

●話 Chat

●卡 Card

●遊戲 Game

●醫療 Medical

●連接 Connect

6. 與你的DIGIMON一起步行
WALKING WITH YOUR DIGIMON

7. 步行狀況 WALKING STATUS

●距離 Step Distance / Step

●D-資源 D-Source

●開始 / 獲勝 Victory / Win

8. 步行中所發生的事情 EVENT WHILE WALKING

9. 勝敵 DIGIMON
BATTLE WITH ENEMY DIGIMON

●戰鬥 Battle card

●交換 Change

●逃走 Escape

●戰鬥四戰 Four fight

10. 當你完成你的距離
WHEN YOU REACH YOUR DISTANCE

注意 ! CAUTION !

- 持有產品者請細閱本說明書。
- 勿讓未滿歲的小孩玩此產品。
- 本產品含有小零件如電池及螺絲等細小零件，小孩勿讓兒童吞入口，以免引起窒息的可能。
- 電池，電池蓋及螺絲等細小零件可能被吞食。請勿將本產品給3歲以下幼兒。
- 更換電池時，請找成人來幫忙，注意勿讓吞下電池。電池蓋，螺絲等細小零件。
- 吞食電池時請勿驚慌。請小心吞食電池在幼兒不好的地方。
- 電池由本產品持有人更換。
- 電池由本產品持有人更換。
- 勿將新舊電池混合使用。切勿將不同種類的電池混用。
- 請定期充電及正確放置。
- 勿充過充電，分離，加熱或棄於火中。
- 吞食電池異常危險，萬一誤吞電池，請即時就醫。
- 請勿將電池拆卸或摺曲。
- 玩具部分操作細小，小心勿讓細小零件放入口。
- 本產品可能有包裝上圖示及說明書所示少許偏差。
- Content may vary from photos and illustrations shown on the package.
- Ages 4 & up.
- Conforms to safety standard EN 71.

3. 按C鍵，Digimon的屬性會顯示於畫面。
(若在畫面上顯示Digimon成熟期或完全體的進化類型，你可按下A鍵和B鍵來觀察兩者的不同之處。)
Selected Digimon's TYPE will appear on screen by pressing button C.
(If you are showing TYPE of Digivolving Digimon Champion or Ultimate level on screen, You can press button A and B to see different TYPE of Champion or Ultimate level of Digimon.)

4. 按C鍵便可以看見Digimon的生命值和攻擊數值。

Digimon's LIFE AND ATTACK will appear on screen by pressing button C.

5. 按A或B鍵可以查閱Digimon的生命，攻擊，官能及速度。

Press A or B button to check LIFE, ATTACK, SENSE and SPEED.

6. 按C鍵返回主畫面。

Press D button to go back to main screen.

●若於15秒內沒有按下任何鍵，會返回主畫面。

If no button is pressed within approximately 15 seconds, the display will return to the main screen.

7. 地圖 MAP

查看地圖指標。按A或B鍵，你便可以在遊戲開始時看見4幅地圖。你還可以按C鍵，然後按A或B鍵，便可以查閱各幅地圖的圖示。

Viewing the MAP command. You can view 4 MAPS at the beginning of adventure by pressing button A or B. You can press button C and then A or B to check Area number in each MAP.

8. 在商店查閱商店 CARD SHOP

按C鍵你所收集到的東西。

Press C button to select what you collected.

9. 喻示 CARD

1. 喻示顯示於畫面，請按C鍵。

Press C button when "card" is displayed on the screen.

2. C鍵選擇

Press C button to select.

●D-Power Ver 3 有10張不同款式的遊戲咭。

●你有7張不同款式的遊戲咭。

●你可以在D-SOURCE的咭店交換遊戲咭或當你在Area Boss勝利時獲得。

●每種咭最多可以用4張，但是總共不可以超過32張。

●Total 10 kinds of cards are in D-Power Ver 3.

●You have 7 kinds of cards at the beginning of adventure.

●You can exchange cards in card shop by D-SOURCE or get a card after win to Area Boss.

●You can have maximum 4 cards per kind. But you can't have over 32 cards in total.

10. 在商店查閱商店 CARD SHOP

按C鍵你所收集到的東西。

Press C button to scroll through your collected cards by pressing button A or B. If you already have 32 cards, you can not get new card. You can delete card by pressing button C, A or B and C again. Please see 5 Digi-Command / 3.CARD / 3.CARD / 3-5. 最後按B鍵一次，按A或B鍵取消及返回咭店。

Pull the devices apart and watch them battle. The first Digimon to win four rounds wins the battle!

11. 在商店查閱商店 CARD SHOP

按C鍵你所收集到的東西。

Press C button to scroll through your collected cards by pressing button A or B. If you already have 32 cards, you can not get new card. You can delete card by pressing button C, A or B and C again. Please see 5 Digi-Command / 3.CARD / 3.CARD / 3-5. 最後按B鍵一次，按A或B鍵取消及返回咭店。

12. 在商店查閱商店 CARD SHOP

按C鍵你所收集到的東西。

Press C button to scroll through your collected cards by pressing button A or B. If you already have 32 cards, you can not get new card. You can delete card by pressing button C, A or B and C again. Please see 5 Digi-Command / 3.CARD / 3.CARD / 3-5. 最後按B鍵一次，按A或B鍵取消及返回咭店。

13. 救你的Digimon 伙伴
Save your Digimon Pals

當你看見商店內的夥伴，按C鍵擊破觸手，你便能拯救被綁架的夥伴。

Save your Digimon Pals

Some of Digimon Pals and Kidnapped Digimon can be saved when you see the hole with big stuff. Strike button C to break the stuff.

14. 撃敗你的Digimon 伙伴
Strike your Digimon Pals

按C鍵擊破觸手。

Strike C

擊敗 C

Strike C

擊敗 C

Strike C

擊敗 C

Strike C

1. 什麼是 D-POWER DIGIVICE ? WHAT IS A D-POWER DIGIVICE ?

D-POWER是DIGI-DESTINED在新的第3季電視節目中所使用的最新的DIGIVICE - DIGI-DESTINED使用D-POWER令他們的DIGIMON變身成為凶狠的怪物並幫助他們打敗魔鬼DIGIMON。乘載戰鬥和變身技能幫助DIGIMON變得更強並與戰鬥聯繫。

The D-Power is the newest Digivice used by the Digi-Destined in the new Season 3 Television show.

The D-Power used their D-Power to help them Digivolve their Digimon into fiercer monsters to help them defeat the Evil Digimon. By swiping Battle Cards or Digivolve Cards you help Digimon to be more powerful to win the battle!

by

resetting

the

D-Power

and

the

Digimons

to

be

more

powerful

to

win

the

battle

!

by

swiping

the

card

!

by

resetting

the

D-Power

and

the

Digimons

to

be

more

powerful

to

win

the

battle

!

by

swiping

the

card

!

by

resetting

the

D-Power

and

the

Digimons

to

be

more

powerful

to

win

the

battle

!

by

swiping

the

card

!

D-POWER是DIGI-DESTINED在新的第3季電視節目中所使用的最新的DIGIVICE - DIGI-DESTINED使用D-POWER令他們的DIGIMON變身成為凶狠的怪物並幫助他們打敗魔鬼DIGIMON。乘載戰鬥和變身技能幫助DIGIMON變得更強並與戰鬥聯繫。

The D-Power is the newest Digivice used by the Digi-Destined in the new Season 3 Television show.

The D-Power used their D-Power to help them Digivolve their Digimon into fiercer monsters to help them defeat the Evil Digimon. By swiping Battle Cards or Digivolve Cards you help Digimon to be more powerful to win the battle!

by

resetting

the

D-Power

and

the

Digimons

to

be

more

powerful

to

win

the

battle

!

by

swiping

the

card

!

by

resetting

the

D-Power

and

the

Digimons

to